

AssetPack -3 ATEX & Non-ATEX Cage Installation Guide



NOTE: This installation guide applies to non-ATEX Cages and ATEX Cages which are white with a UV resistant polycarbonate shield. For additional information, please refer to the AP3 Quick Start and User Guide.

01 Identify Mounting Location

- Identify a FLAT & SOLID area, with a WIDE-OPEN VIEW to the sky. Not shaded (by roofs, overhangs, covers, pipes etc.)
- Install the AP3 OUTSIDE, exposed to weather, with "THIS SIDE TO SKY" and the solar panel face up to the sun

FOR BEST PERFORMANCE

- Mount the AP3 on TOP of asset
- The AP3 should be mounted horizontally (parallel to ground) or vertically (perpendicular to ground)
- Do not put the AP3 inside any vehicle

02 Turn the AP3 on

- Remove the magnet from the "OFF" position
- Lock the magnet in place under the plastic tab in the "ON" position
- You will hear a sound indicating the unit is on. It can now be installed.

Refer to the AP3 QuickStart Guide or the User Guide for additional information.



03 Install the AP3

- Place the AP3 where "THIS SIDE TO SKY" and the solar panel are facing up
- Install One 3mm - thick pad on each side in the recesses provided
- Place the cage over the AP3
 - No adhesives or fasteners are used to fasten the AP3 in the cage
 - The AP3 will only fit in the correct orientation. If the 6-pin connector hits the cage, turn the AP3 around in the cage.
- Use fasteners that will stand up to weather and resist corrosion
 - Fasten the cage in place with four M6.35 x 25mm Self Drilling 402 Stainless Screws
 - Alternately four # 14 x 1" Self -drilling 402 Stainless Screws can be used



04 Record the Asset IDs and the AP3 IDs

Record AP3's IMEI (the serial # on the front of the AP3) and the ID # of the asset that it is attached to

For additional questions and documentations, please contact your account administrator or AssetLink's Customer Support Team at support@assetlinkglobal.com or call +1 303-863-8745, Monday – Friday 8:00AM – 5:00PM MST.